

# 4 LINK CLOSER™ MOUNTING INSTRUCTIONS

## Horsch Maestro Planters

Before working on your planter or drill

**DANGER:** When storing or working on the planter always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.

**PLEASE:** Read instructions completely and verify all package contents before beginning installation



**NOTE:** The spring eye bolt has intentionally been left loose from the factory. **Install this bolt to the OPPOSITE side of the front G2/G3 arm.** This will prevent the G2/G3 arm bracket from hitting the eye bolt.



4 Link Closer for Horsch Maestro Package Contents (per single row)	
Item	Quantity
4 Link Closer Assembly . . . . .	4
1/2" x 1-1/2" Carriage Bolt . . . . .	4
1/2" Whiz Nut . . . . .	4
M12-1.75 x 25mm Bolt . . . . .	2
M12 x 24mm OD DIN Flat Washer . . . . .	2
Mounting Bracket . . . . .	1

- #1:** Remove bolts and allen head bolts from existing tail section. Remove springs and drop off the old tail section.
- #2:** Place mounting bracket as shown in images below, and hold in place with carriage bolts and whiz nuts on each side (tighten later). Do not re-use the stop bolts. Insert M12 bolts and washers in place of the original allen head bolts.
- #3:** Swing 4LC up and install carriage bolts from bottom of 4LC through the slotted holes and shoulder mount brackets. Retain with whiz nuts.
- #4:** **Align 4LC with row units and double tighten carriage bolts and whiz nuts down so they don't come loose while running in the field.**
- #5:** **Tighten all mounting hardware 2X.**

Horsch row unit

