

PRESSURE GAUGE PARTS & MOUNTING


Remote or Tower Mount

Before working on your planter or drill

DANGER: When storing or working on the planter always install cylinder stops or place the planter on stands to prevent personal injury or damage to the attachments.


PLEASE: Read instructions completely and verify all package contents before beginning installation.

GX1 TOWER MOUNT GX2 TOWER MOUNT



Pressure Gauge Package Contents (single)	
Item	Quantity
ASG604 (4" Pressure Gauge) or ASG60 (2" Pressure Gauge)	1
QC9.	2
QC4.	2
RB075-025 (3/4" male to 1/4" female NPT) . . .	1
3T34F (T body)	1
H12 (12# Hose Clamp)	2
Mounting Option #1: Remote Location	
MG-MOUNT (Magnet + Mount Bracket assy.) .	1
Mounting Option #2: Tower Mount	
MAGNET MOUNT BRACKET	1
1/4" x 5/8" Bolt	1
1/4" Nut	1

T FITTING ASSEMBLY



inlet from pump

to manifolds

REMOTE GAUGE MOUNT



REMOTE LOCATION KIT



TOWER MOUNT KIT

